

## Burst Powercore Accessory Kits – Assembly



*These handy kits allow you maximum creativity and control using the new Burst and Compact Burst Powercore fixtures from Philips Color Kinetics.*


**For Use with:**

Philips Color Kinetics Burst Powercore

Philips Color Kinetics Compact Burst Powercore

Part Number	Description
4766.AC4	Accessory Kit for Compact Burst Powercore
4766.AC6	Accessory Kit for Burst Powercore

The same instructions apply to both the 4766.AC4 and 4766.AC6 kits. 47766.AC6 is shown here.



**Burst Spread Lens**  
If using one of the spread lenses available from Color Kinetics, install this first, in accordance with the manufacturer's instructions

**Accessory Holder**  
Back off the six socket cap screws and slip the accessory holder over the front of the Burst fixture. Tighten the three screws (A) to lock into the groove (G)

**Filter Frame (optional)**  
Insert a piece of filter medium between the two sides of the frame and trim around to fit, then insert the frame behind the accessory ears (E)

**Finally:**  
Tighten the three Accessory Clips (C) down on the accessories used and lock with the screws provided.